

A white line-art illustration on a black background. In the center is a tablet with a small circle on its left edge. To the left of the tablet is a game controller with a joystick, a directional pad, and buttons labeled 'SELECT', 'HOME', and 'START'. Above the joystick are buttons labeled 'SEARCH' and 'CHARGE'. To the right of the tablet is another game controller with a joystick, buttons labeled 'Y', 'B', 'X', and 'A', and a set of four action buttons. The Quantum logo is visible on the top of this controller.


# ***BLUETOOTH GAMING AND FPV SIM CONTROLLER***

**USER MANUAL**

**QUANTUM**



# BLUETOOTH GAMING AND FPV SIM CONTROLLER



- ▶ **GamePad Mode** (X) + (HOME) : Only Android 3.2 + versions supports this mode. When the handle is turned off, first press the "X" key, then press the HOME key, at the same time, the Bluetooth LED indicator will flash. The handle is now in pairing mode and turn on the phone Bluetooth and search Bluetooth devices. Find "**Quantum Game Pad**" for pairing. LED indicator light will stay on after successful pairing.
- ▶ **Keyboard Mode** (A) + (HOME) : (For Android system and various types of simulators) When the handle is turned off, first press the "A" key, then press the HOME key. The Bluetooth LED indicator will flash. The handle is now in pairing mode and turn on the phone Bluetooth and search Bluetooth devices. Find "**Quantum Game Pad**" for pairing. LED indicator light will stay on after successful pairing.



- ▶ iCade mode **(B) + (HOME)** : (Before pairing, please change the default keyboard input to English)When the handle is turned off, first press the "B" key, then press the HOME key.The Bluetooth LED indicator will flash. The handle is now in pairing mode and turn on the phone Bluetooth and search Bluetooth devices. Find "**Quantum Game Pad** " for pairing. LED indicator light will stay on after successful pairing.
- ▶ Y.Y key has two modes **(Y) + (HOME)** : 1.SPP Mode (for systems with virtual keys of the game), 2.Android handle Assistant  
1.SPP Mode: When the handle is turned off, first press the "Y" key, then press the HOME key. LED lights flash and the handle enters into the pairing mode. If the pairing is successful, the LED indicator will stay on.The handle is now in SPP mode; SPP mode requires corresponding Android APP software to complete the relevant key mapping function.
- ▶ Mouse Function: When the controller using GamePad or Keyboard mode to connect the phone and connection is successful, press "**(Y) + (HOME)** " key to switch to mouse mode, this function is performed by three function keys to operate: the right joystick (control cursor to move), L1 (confirmation), R1 (return).

## Introduction:

This product is a new wireless Bluetooth controller which supports different android/ ios/ PC games.

-It can be used when connected with the Bluetooth mobile phone and without any drivers.

-Exclusive gaming application platform, the classic hand travel under control (Android handle Assistant only for Android platform).

-Built-in lithium battery (380mAh). After charging, it can be used for 18 hours.

-With "volume +, -, "last ", "next ""Play / Pause" , total 5 multimedia function keys (This function is incompatible with Y key mode.)

-Bluetooth 3.0 wireless transmission can support 6-8 meters range of control from the phone/tablet.

-Support android 3.2, ios 4.3 above system.

-Compatible with WinXP/Win7/Win8,Android TV Box(which can support bluetooth function), Android TV.



## **Game Support Description:**

Under Android system, it supports the vast majority of games and simulator games (such as MC4, Wild blood, Dungeon Hunter, Zombie, FC simulator, GBA emulator, arcade emulator, SFC simulator, N64 emulator, Shadowgun, Sonic CD, Cordy, soulcraft, Zenonia4, 9 Innings 2013, Riptide GP, Freerider etc.)

Mouse mode compatible games: Such as Fruit Ninja, Pleants VS Zombies, Flappy Bird, Angry Birds, Sky Force, Airattack HD, Cut the Rope, etc.

## **Some of IOS games:**

Muffin Knight – Angry Mob Games

Box Cat – Rusty Moyher

Midway Arcade – Warner Bros.

Super Lemonade Factory – Shane Brouwer

Gold Runner – YOMEN, Inc.

Minotron: 2112 – Llamasoft

No Gravity – Realtech VR

Space Inversion – Silverline Arts

Emerald Mine – Les Bird

Commodore 64 – Manomio LLC

Kung Fu Rabbit – Bulkypix

Temple Run – Imangi Studios, LLC

PAC-MAN for iPad – Namco Networks America Inc. Games

Blast Ball – UNCADE

Retro Racing – Mr Qwak Limited

Velocispider – Retro Dreamer

Super Mega Worm – Deceased Pixel LLC

Sideways Racing – Bjango

Freeesh – Realtech VR

Compression HD – Little White Bear Studios, LLC

The Exterminator – SUMO Productions

IronStar Arena – Appracatappa, LLC.

Mos Speedrun – Physmo

Plum Crazy – Claymore Games

Cyborg Livestock – PopArcade

Stardash – OrangePixel

GoatUp – Llamasoft

Bob's Action Racing – VariaMedia GmbH

Match Panic – Chaotic Box

Fruity The Snake HD – 22Moo

Haunted Hallway – UNCADE

Battlestation – CrushCrumble

Influx – Half Fast Games

Rush City

Slfpart2

Warblade HD – Edgar Vigdal

HungryMaster – xionchannel

Space Inversion 2. – Silverline Arts

Super Drill Panic – OrangePixel

Minotaur Rescue – Llamasoft

Silverfish MAX – Chaotic Box

Retroid – Flat Black Films

AirAttack HD – Art In Games

HyperBow! – Technicat, LLC

Jungool – Headsoft

Akane Lite

Lemonade



## User Manual:

SPP use: (\*Note: This is optional for rooted devices only.)

1. Go to Settings → Language and input → Select Input Method "GHTouch IM" which is available from the product page at Hobbyking.com under the Files tab. (Figure 1)




Figure 1



2. Open the application "GHTouch" → Choose device " **Qunam Game Pad** " → check "virtual screen buttons"  
→ Select Input Method "GHTouch IM" → The device will automatically connect with the handle, after the connection is completed , will stay on (Figures 2, 3)

3. After entering the game, press the volume up on the device or handle "Select" button, the button icon onto the screen corresponding to the position (Note: Double-click the icon to set the size), press return or click on the device handle "Select", icon hidden, complete the setup.




Figure 2




Figure 3



- ▶ **Input method setting:** Using the controller to play games set the phone or notebook input method to be default as English language input (For ios system, be sure to switch the input method, then pair. If not, the handle will not work properly.)
- ▶ **Charging controller:** USB charging (PC device or mobile phone power adapter). During charging the charge indicator light of handle is orange and LED will turn off after fully charged.
- ▶ **Switch on/off the controller:** Press "HOME" button for 3 seconds until the Bluetooth LED turns off.  
If the phone unpairs connection when controller turns off. Just pair again.  
Press the "HOME" button for about five seconds, until the LED red light flashes slowly. It means that the handle is turned on (the default last boot mode), the boot handle will automatically paired with the phone connection. If the connection fails, the handle will automatically shut down.
- ▶ **Connect to the PC:** Open the device's Bluetooth PC program, and select the "X, A" in either mode can be paired

**Note:** To change the controller function mode, please turn off the controller first and cancel the bluetooth pairing, then in accordance with the operation mode to retry the pairing steps.

### **Attention:**

1. When the controller can't operate normally, please use the paperclip to touch the reset switch on the left corner of the grip back when the game pad cannot shut down or crashes.
2. Please do not put this product in wet or hot places for storage.
3. Do not hit, beat, pierce or attempt to disassemble the product to avoid unnecessary damage.
4. Do not discard the built-in battery with garbage.
5. Do not use near fires or other heat sources while recharge the battery.